



WIRELESS MESSAGING - ANSWERING SERVICES

VOICEMAIL / NUMERIC RETRIEVAL / CUSTOM GREETING INSTRUCTIONS

- 1) **Call your pager number.**
- 2) **When the existing prompt begins; press the “Star” button.**
- 3) **When you are prompted; enter your security code.**
- 4) **You will be told how many new messages you have and you can choose from the following:**

Main Menu

7 Play Messages Menu

- 7 Review First Messages
- 3 Delete Message
- 4 Scan Messages
- 5 Save Message
- 6 Skip Back 2-4 Seconds
- 7 Replay This Message
- 8 Play Time and Date of Current Message

OR: To choose “User Option Menu”, after entering security code, press 8.

- 4 Record a Personal Greeting
 - Record Your Greeting Then Press #
 - 2 To Accept and Save Greeting
 - 3 To Discard and Record a Different a Greeting
 - 5 Listen to Your Recording
 - # To Quit and Return to User Options

- 7 Change Your Security Code
 - Input Your New Security Code
 - 2 To Accept and Save Your Security Code
 - 3 To Enter a Different Security Code
 - # To Quit and Return to User Options

- 8 More User Options
 - 4 To Erase Your Greeting
 - # To Quit and Return to User Options

800-666-8995

www.ContactAnswers.com